2018/11/24 21:55 1/1 Loop Attenuation

Loop Attenuation

Loop Attenuation is a measure of the quality of the line - how much the signal weakens over the loop.

Attenuation is measured in Decibel (dB). A value betwen 20dB-45dB can be considered normal.

From:

http://docs.intenogroup.com/glossary/ - Inteno Glossary

Permanent link:

http://docs.intenogroup.com/glossary/l/loop_attenuation

Last update: 2018/08/10 18:16

